

# KIRA TECH TIP

## Auto Set of Work Offsets

Jog spindle manually over part zero

<Offset><Work> Cursor to proper fixture offsets

Press <X0><Measure>

<Y0><Measure>

Position will automatically be recorded