

KIRA TECH TIP

Avoid Drilling A Hole when Defining a Drill Cycle

Program the modal conditions first:

```
G81 Z____ R____ F____ K0  
M98 P1234
```

The K0 will not allow a hole to be drilled on the G81 line. Put all hole dimensions in a subroutine.